

## Carenado Super Cargomaster conversion installation instructions

This package will convert a Carenado C208B Grand Caravan v3 installation into a C208B Super Cargomaster v3. Please read these instructions carefully, in order to ensure a correctly functioning product. NOTE: Please ensure that you are working with the Caravan v3. This expansion pack will NOT work with v1.0 or 2.0 of the Caravan.

1. Create a copy of your existing "Carenado C208B Grand Caravan v3" folder.
2. Rename it to "Carenado C208B SuperCargomaster". CAUTION: if this file name is too long, the plug-in won't load correctly on some systems. Please make sure the file name is exactly as described. If your plane's plug-in does not load after installation, try shortening the folder name.
3. Delete the "liveries" folder.
4. Unzip the downloaded file. Keep the originally downloaded .zip archive file stored somewhere safe as a backup copy.
5. Once unzipped, the folder should contain some files and folders. Drag or copy all files and folders, EXCEPT the one titled "Copy contents into OBJECTS folder" into the copy of the Caravan folder that you wish to convert to the Cargomaster, replacing all files when prompted.
6. Open the folder titled "Copy contents into OBJECTS folder." Select and copy & paste or drag all these files into your Cargomaster's "objects" folders.

This should convert the copy of the Grand Caravan v3 into a Super Cargomaster v3.

To download extra FedEx and UPS liveries, please go here:

<http://www.carenado.com/CarSite/Portal/pages/Freeliveriesc208xplane.php>